Installation Instructions

Tel-Card
Pre-Paid Calling Cards

Read this first!

Please read these Installation Instructions before unpacking the CD-ROM and the Tel-Card calling cards!

The CD-ROM content needs to be READ into a Tel-Log unit with the Soft-Log Administration software and the cards must be ACTIVATED before they can be sold and used!

---

1 Unpack the CD-ROM and import card package

Unpack the CD-ROM and insert it into a CD-ROM drive on the computer running the Soft-Log application.

Run Soft-Log and connect to the unit where you plan to use the cards in your new card package.

In Soft-Log select the **Prepaid Tel-Cards** branch and click the **Right Mouse Button** to open the context menu where you can select **Import...** and point to the card package file on the CD-ROM and read the content of the disk into Soft-Log.

This is the Card Activation Code used in Soft-Log to activate the card before it can be used!

This is the Key Code assigned to the card after it has been activated and is ready for use in Tel-Log!

How to use the *Tel-Card*
Locate the nearest Tel-Card telephone
Pick up the handset and wait for dial tone
Enter the PIN number
Wait for new dial tone
Dial the telephone number

2 Make sure your settings are correct

The card value is predetermined (i.e. €20). For the cards to be correctly activated in your system you must make sure your **Price pr. Unit** and the **Markup Percent** (if you want to use Markup) is correctly configured before you proceed to Activate any cards. These settings can be viewed and adjusted on the **General** page of the **Tools->Options** window.

## 3 Activate cards before selling or using them

Proceed to Activate the cards you want to sell so they become active in your Tel-Log unit and can be used.

In the **Prepaid Tel-Cards** branch, select the card(s) you want to activate (you can select more than one card at a time by holding down the **Ctrl** button while selecting cards from the list with your mouse or press **Ctrl-A** to select the entire list) and click the **Right Mouse Button** over any selected card to open the context menu where you can select **Activate...**

Prepaid Tel-Cards

Show Items Assigned To: Any Line

Activation Code	ID	Trunk Barrin...	Amount	Line Assignment	Imported
10001	20	1-16	20	1-16	7.9.2002
10002	20	1-16	20	1-16	7.9.2002
10003	20	1-16	20	1-16	7.9.2002
10004	#IF	None	20	1-16	7.9.2002
10005	#IF	None	20	1-16	7.9.2002
10006	#IF	None	20	1-16	7.9.2002
10007	#IF	None	10000	1-16	7.9.2002

(context menu: Activate..., Delete, Export...)

4 Your Cards are now Pre-Paid Key Codes

When the cards from the Card Package have been Activated, they become **Key Codes** in the Tel-Log unit and appear under the Key Codes branch in the tree.

Activate Tel-Cards

By Activating Tel-Cards they become KeyCodes in your Tel-Log Unit. Tel-Card KeyCodes are configured for Pre-Paid use only. The initial Unit balance is determined by the following settings.

System Settings
Price pr. Unit: 1 EUR
Markup Percent: 0%

Change Settings...

Activating Multiple Tel-Cards

Activate   Cancel